



**Ruger 10/22 Bolt Buffer  
Installation Instructions**  
V1.0

[www.tandemkross.com](http://www.tandemkross.com)

For more info or support contact [CustomerService@tandemkross.com](mailto:CustomerService@tandemkross.com)

**Attention: Before you begin, be certain that the firearm is safe.**

*Always wear eye protection when working on firearm parts.*

*Tools you will need:*

- *A punch and mallet/hammer*

Step1: Remove the receiver from the stock.

Step 2: Using a punch, remove the existing metal buffer from the receiver.

Step 3: Install the replacement buffer into the same hole as the original metal buffer. Ensure that it is flush on both sides. Some shaving may occur on the buffer when it is punched into the opening.

Step 4: Reinstall the receiver into the stock.

