



“Accelerator” Thumb Ledge for Keltec PMR30 and CP33 Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention:

Before you begin, be certain that the magazine is removed and the chamber is clear.

You will need a 2.5 mm allen wrench, and a punch if necessary.

1. To begin this installation, use the 2.5mm allen wrench provided with the kit to remove the allen screw directly below the takedown pin.



2. From the right hand side push the takedown pin out slightly so that the lip of the pin will be accessible. Use a punch if necessary.



3. Slide the Accelerator onto the takedown pin and position it so that you can put the extended allen screw through the frame of the gun. Then tighten the allen screw.



4.

Installation is complete! Enjoy your new Tandemcross Accelerator Thumb Ledge!

