

"Cornerstone" Safety Thumb Ledge for Keltec PMR30, CMR30 and CP33 Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention:

Before you begin, be certain that the magazine is removed and the chamber is clear.

You will need a 5/64" or 2mm allen wrench.

1. Place the gun so that the right side is down. Set the safety switch to fire.



2. Use the allen wrench to loosen the screw on the safety lever by turning it counter-clockwise.



3. Remove the old safety lever, keeping in mind where the slots of the safety mechanism are.



4. Place the "Cornerstone" thumb ledge safety into the safety mechanism, ensuring that the slot on the thumb ledge aligns with the key on the safety mechanism.



5. Replace the retaining screw, turning the allen wrench clockwise until the safety switch moves to the up position. To ensure that the safety is tightened, switch it between safe and fire, and check for any movement. If there is none, you have completed the installation correctly!

