



# "Kross Out" Safety Delete for the CZ Scorpion Installation Instructions V1.0

[www.tandemkross.com](http://www.tandemkross.com)

For more info or support contact [CustomerService@tandemkross.com](mailto:CustomerService@tandemkross.com)

## Attention:

Before you begin, be certain that the magazine is removed and the chamber is clear.

You will need a 1.5mm allen wrench

1. Lock the bolt in the retracted position.



2. Identify the takedown captured pin. Push the pin from the right side to the left side of the firearm and remove the trigger sub-assembly



3. Rotate the safety to the fire position to align the set screw with the slot. Using a 1.5 millimeter allen wrench remove the set screw from the safety switch and remove the safety switch.



4. Align the line on the safety delete with the line on the safety switch. Install the "Kross Out" Safety Delete using the original set screw. Re-install the trigger sub-assembly.

You have completed the installation!

