



**Front Fiber Optic Sight  
for Taurus™ TX-22  
Installation Instructions  
V1.0**

[www.tandemkross.com](http://www.tandemkross.com)

For more info or support contact [CustomerService@tandemkross.com](mailto:CustomerService@tandemkross.com)

**Attention:**

**Before you begin, be certain that the magazine is removed and the chamber is clear.**

---

You will need a 5/64" allen wrench and a 1.5 mm allen, both are included with sight

---

1. Remove the slide, recoil spring and barrel.



2. Remove the original front sight using the 5/64" allen wrench.



3. Locate the included 2.5mm screw. (Do not use original screw to install new fiber sight, the thread size is different)



4. Place the sight into the slotted hole in the slide with the serrated face toward the rear of the firearm.



5. Install the brass washer on the screw and firmly tighten the screw using 1.5 mm allen wrench while keeping sight in proper alignment.

6. Install the barrel, recoil spring, and slide.

You have successfully completed the installation. Enjoy your new TANDEM KROSS TX-22 Front Fiber Optic Sight.

