



Ruger LCP Tool-less Takedown

Pin

Installation Instructions V2.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention: Before you begin, be certain that the firearm is clear and safe.

Remove the magazine and double check the chamber to make sure that no rounds are in the pistol.

1) Remove the stock takedown pin as shown in the pistol's manual. Do this by locking the slide back and pulling the top lip of the face of the pin with a small object such as a knife. Be careful not to mar your slide's finish. With slight force, the pin should slide right out. Be sure to hold the gun steady and in place, so as not to alter the alignment of the hole.



2) Orient the TANDEMKROSS Tool-less Takedown Pin so that the slot in the pin is facing down before installation.

3) Insert it with downward pressure to push the retaining spring down. Make sure that the slot of the pin is locked into the retaining spring and that the **indentation mark on the head of the pin is in the DOWN position**. The pin is engaged when the head of the pin is nearly flush with the face of the frame. This is the secured and locked position for the pin.



4) Verify that the TANDEMKROSS Tool-less Takedown Pin is secure and in the locked position by pulling out on the pin. It should not budge.

**For pistol disassembly, you can use your fingernail and rotate the indentation to the UP position and then pull out the pin.*