

Attention:

Before you begin, be certain that the firearm is clear and safe.

It is recommended to wear safety glasses as some parts are under spring tension. You will either need two small punches, allen wrenches, or small drill bits in order to install this part.

Package includes one (1) "Eagle's Talon" extractor A thin pick or punch is required for installation.

- Push the takedown pin located near the safety until it's flush with the surface of the gun. Turn the gun over and pull the pin as far out as it will go from the other side. Push up on the charging handle to separate the upper from the lower.
- 2. Remove the bolt and charging handle from the upper.

3. Use the pick to depress the spring that the extractor is seated on. The extractor should now be able to be removed easily. Be careful not to let the spring and plunger go flying.







4. Put the new extractor in the bolt.

5. Put the bolt back in the upper and close the gun.Push the takedown pin back through.



