



Ruger MK III/IV "Titan" Extended Magazine Release Installation Instructions

V1.0

www.tandemkross.com

For more info or support contact CustomerService@tandemkross.com

Attention: Before you begin, be certain that the firearm is safe.

Remove the magazine and inspect the chamber making sure that it is empty.

We recommend that if you are not comfortable with disassembly of your gun that you consult a gunsmith. This is a simple job for an experienced gunsmith but it can be challenging if you are not experienced with the inner workings on the Ruger MK IV.

These instructions were written using the MK IV, but apply to the MK III as well.

Comes with 1 "Titan" Extended Magazine Release, 1 5-40 Screw, 1 Round Button, 1 Paddle Button, 1 spacer

1. Follow the Owner's Manual for field stripping the Ruger MK IV.
2. Remove the left grip plate.
3. Unscrew the screw holding the factory Magazine Release in place and set it aside. **Be sure not to lose it as it is very small.**
4. The magazine release will slide out from the grip frame from RIGHT to LEFT. **Be aware that if the magazine release is not the factory release, a spring and plunger may slide out from the magazine release.**



5. Locate the spring and plunger in the magazine release. If it is a factory release button, the spring and plunger may be stuck inside. Use a dental pick or similar tool to gently remove them.
6. Install the spring and plunger inside the "Titan" Magazine Release.



7. Insert the "Titan" into the grip frame, lining up the peg on the "Titan" with the slot in the opposite side of the frame. Replace the small screw removed earlier.



8. Install the button style of your choice: round or paddle. If installing the paddle, adjust the paddle to the desired position.

If you have grip panels thicker than the factory standard, you may have to install one or more spacers.

9. Test the "Titan" with an **empty** magazine before reinstalling the grips.

