

www.tandemkross.com

For more info or support contact <a href="mailto:CustomerService@tandemkross.com">CustomerService@tandemkross.com</a>

## Attention:

Before you begin, be certain that the firearm is clear and safe.

Package Contents: 1 "halo" Charging Ring,

1 5-40 3/4" cap screw, 1 allen wrench.

The "Halo" Charging Ring is designed to fit onto Ruger Mark II.

Step 1: Lock the bolt back in the open position. This allows easy access for attaching the charging ring to the bolt.



Step 2: Slide the "halo" Charging Ring onto the back of the bolt, perpendicular to the bolt grips.

Step 3: Twist the "halo" Charging Ring so that it is level with the bolt. The curved side should be facing down.



Step 4: Install and tighten the included 5-40 3/4" socket cap screw. Do not overtighten the screw. The charging ring grips tightly to the bolt. Some blue loctite on the threads of the screw is recommended to keep it from loosening.

