



## Kel-Tec Sub 2000 Single Point Sling Mount Installation Instructions

V1.1

[www.tandemkross.com](http://www.tandemkross.com)

For more info or support contact [CustomerService@tandemkross.com](mailto:CustomerService@tandemkross.com)

### **Attention:**

**Before you begin, be certain that the firearm is safe.**

*Remove the magazine and inspect the chamber making sure that it is empty.*

Your kit includes:

- a Sling Mount
- a nylon patched screw
- an Allen wrench



**Follow the manual's instructions to disassemble your rifle.** Do this by making sure the bolt is in the forward position, the hammer cocked, and safety engaged.

1. With the included Allen wrench or other tool, push the stock pin in and then pull it with you fingers from the other side until it locks. The buffer cap and recoil spring can now be removed as well as the bolt by pulling back on the operating handle.



2. The entire buttstock will now need to be removed by removing the stock pin even further than the stopping point groove machined into it. This is done by lining up the detent (green arrow) with the center cut out in the pin (red arrow) and then rotating the pin counter-clockwise such that the detent no longer rides in the groove of the stock pin. We recommend to slowly pull the pin out a bit more so that the stock can be slid off but still have the pin retain the detent if possible.



*\*If the pin is completely removed, use your thumb nail inside the back of the buttstock to depress the detent while simultaneously rocking the tip of the pin back into the hole.*

3. Now you will be able to slide the TANDEMKROSS Single-Point Sling Mount onto the back of the bolt tube and slide it as far as it will go on the collar. Insert the provided screw from the non-threaded side first to the threaded side of the mount and use the Allen wrench to tighten the sling mount securely. The mount acts as a clamp on the receiver nut. **Be careful not to over tighten or you will damage your rifle. The sling mount will hold tightly without having to over tighten.**



4. Reverse the above process and follow the steps in the rifle's manual for reassembly.